



Quick Start Guide

NE200/300

Variable Speed AC drive

Part number: 31019007

Version: V1.7



Scan QR to follow us



Revision History

Date	Version	Description
2020/4/7	1.0	Issued for the first time
2020/5/19	1.1	Add “Modbus Address” column in parameter brief list
2021/1/19	1.2	1、Add parameter F2.35,F2.36,F7.37~F7.41,modify the default value of F3.38, F3.39,F3.42,Fd.00. 2、Update the nameplate, add the inspection certification in the last page
2021/2/22	1.3	Update figure 4-3
2021/4/16	1.4	Update CT logo to the newest version in all related drawings
2021/6/18	1.5	Update the last page “inspection certification”
2021/6/23	1.6	Update figure 3-3
2021/9/18	1.7	Modified the Chinese characters in the “setting range” column of parameter F7.26

1. Safety Precautions

1.1 Description of safety marks

 **Warning:** A Warning contains information which is essential for avoiding a safety hazard.

 **Caution:** A Caution contains information which is necessary for avoiding a risk of damage to the product or other equipment.

1.2 Use

Warning

- This series of inverter is used to control the variable speed operation of three-phase motor and cannot be used for single-phase motor or other applications. Otherwise, inverter failure or fire may be caused.
- This series of inverter cannot be simply used in the applications directly related to the human safety, such as medical equipment.
- This series of inverter is produced under strict quality management system. Redundancy or bypass solution is necessary if the inverter failure may cause severe accident or loss.

1.3 Installation

Caution

- If the inverter is found to be damaged or parts missing, the inverter cannot be installed. Otherwise, accident may be caused.
- When handling and installing the product, please hold the product from bottom. Do not hold the enclosure only. Otherwise, your feet may be injured and the inverter may be damaged because of dropping.
- The inverter shall be mounted on the fire retardant surface, such as metal, and kept far away from the inflammables and heat source.
- Keep the drilling scraps from falling into the inside of the inverter during the installation; otherwise, inverter failure may be caused.
- When the inverter is installed inside the cabinet, the electricity control cabinet shall be equipped with fan and ventilation port.

And ducts for radiation shall be constructed in the cabinet.

1.4 Wiring

Warning

- The wiring must be conducted by qualified electricians. Otherwise, there exists the risk of electric shock or inverter damage.
- Before wiring, confirm that the power supply is disconnected. Otherwise, there exists the risk of electric shock or fire.
- The grounding terminal PE must be reliably grounded, otherwise, the inverter enclosure may become conductive.
- To ensure the safety, the inverter and the motor must be grounded. Please do not touch the main circuit terminal. The wires of the inverter main circuit terminals must not contact the enclosure. Otherwise, there exists the risk of electric shock.
- The connecting terminals for the braking resistor are (+) and PB. Please do not connect terminals other than these two. Otherwise, fire may be caused.

Caution

- The power supply cannot connect to output terminals U-V-W, otherwise, the inverter will be damaged.
- It is forbidden to connect the output terminal of the inverter to the capacitor or LC/RC noise filter with phase lead, otherwise, the internal components of the inverter may be damaged.
- Please confirm that the power supply phases, rated voltage are consistent with that of the nameplate, otherwise, the inverter may be damaged.
- The wires of the main circuit terminals and the wires of the control circuit terminals shall be laid separately or in a square-crossing mode, otherwise, the control signal may be interfered.
- When the length of the cables between the inverter and the motor is more than 100m, it is suggested to use output reactor to avoid the inverter failure caused by the over-current of the distribution

capacitor.

- The inverter which equipped with DC reactor must connect with DC reactor between the terminal of P1、(+) otherwise the inverter will not display after power on.

1.5 Operation

Warning

- Power supply can only be connected after the wiring is completed and the cover is installed. It is forbidden to remove the cover in live condition; otherwise, there exists the risk of electric shock.
- When auto failure reset function or restart function is set, isolation measures shall be taken for the mechanical equipment, otherwise, personal injury may be caused.
- When the inverter is powered on, even when it is in the stop state, the terminals of the inverter are still live. Do not touch the inverter terminals; otherwise electric shock may be caused.
- The failure and alarm signal can only be reset after the running command has been cut off. Otherwise, personal injury may be caused.

Caution

- Do not start or shut down the inverter by switching on or off the power supply, otherwise the inverter may be damaged.
- Before operation, please confirm if the motor and equipment are in the allowable use range, otherwise, the equipment may be damaged.
- The heat sink and the braking resistor have high temperature. Please do not touch such devices; otherwise, you may be burnt.
- When it is used on lifting equipment, mechanical contracting brake shall also be equipped.
- Please do not change the inverter parameter randomly. Most of the factory set parameters of the inverter can meet the operating requirement, and the user only needs to set some necessary parameters. Any random change of the parameter may cause the

damage of the mechanical equipment.

- In the applications with mains frequency and variable frequency switching, the two contactors for controlling the mains frequency and variable frequency switching shall be interlocked.

1.6 Maintenance & Inspection



- In the power-on state, please do not touch the inverter terminals; otherwise, there exists the risk of electric shock.
- If cover is to be removed, the power supply must be disconnected first.
- Wait for at least 10 minutes after power off or confirm that the CHARGE indicator is off before maintenance and inspection to prevent the harm caused by the residual voltage of the main circuit electrolytic capacitor to persons.
- The components shall be maintained, inspected or replaced by qualified electricians.



- The circuit boards have large scale CMOS IC. Please do not touch the board to avoid the circuit board damage caused by static electricity.

2. Introduction to NE200&300

2.1 Product Model Description

The digits and letters of the inverter model number on the nameplate indicate information such as product series, voltage grade, power ratings and hardware versions.




Fig.2-1 Product Model Description

2.2 Product Nameplate Description




Fig.2-2 Product Nameplate Description

2.3 Product Series

2.3.1 NE200 Product Series

- NE200-4T□□□GB Three-phase 400V Constant torque/heavy-duty application

Power (kW)	0.75	1.5	2.2	4.0
Adapted motor (kW)	0.75	1.5	2.2	4.0
Output	Voltage (V)	3phase 0~rated input voltage		
	Rated current (A)	2.5	4.0	6.0
	Overload capability	150% 1min; 180% 20sec.		
Input	Rated voltage/frequency	3phase 380V/440V; 50Hz/60Hz		
	Voltage range	304V~456V; voltage imbalance ≤3%; Allowable frequency fluctuation ±5%		
	Rated current (A)	3.7	5.4	7.0
Braking unit	Inbuilt as standard			
IP rating	IP20			
Cooling	Forced air cooling			

- NE200-4T□□□PB Three-phase 400V Variable torque/normal-duty application

Power (kW)	1.5	2.2	4.0	5.5
Adapted motor (kW)	1.5	2.2	4.0	5.5
Output	Voltage (V)	3phase 0~rated input voltage		
	Rated current (A)	4.0	6.0	9.0
	Overload capability	120% 1min; 150% 1sec.		
Input	Rated voltage/frequency	3phase 380V/440V; 50Hz/60Hz		
	Voltage range	304V~456V; voltage imbalance ≤3%; Allowable frequency fluctuation ±5%		
	Rated current (A)	5.4	7.0	10.7
Braking unit	Inbuilt as standard			
IP rating	IP20			
Cooling	Forced air cooling			

- NE200-2S□□□GB Single-phase 220V constant torque/heavy duty application

Power (kW)	0.4	0.75	1.5	2.2
Adapted motor (kW)	0.4	0.75	1.5	2.2
Output	Voltage (V)	3phase 0~rated input voltage		
	Rated current (A)	2.5	4.5	7.0
	Overload capability	150% 1min; 180% 20sec.		
Input	Rated voltage/frequency	1phase 200V/240V; 50Hz/60Hz		
	Voltage range	176V~264V; voltage imbalance ≤3%; Allowable frequency fluctuation ±5%		
	Rated current (A)	5.3	8.3	14
Braking unit	Inbuilt as standard			
IP rating	IP20			
Cooling	Forced air cooling			

2.3.2 NE300 Product Series

- NE300-4T□□□GB Three-phase 400V Constant torque/heavy-duty application

Power (kW)	1.5	2.2	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110							
Motor power (kW)	1.5	2.2	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110							
Output	Voltage (V)	Three-phase 0 to rated input voltage																					
	Rated current (A)	4	6	9	13	17	25	32	37	45	60	75	90	110	150	176	210						
Overload capacity : 150% 1 minute; 180% 20 seconds,																							
Input	Rated voltage/frequency :Three-phase 380V~440V; 50Hz/60Hz																						
	Max. voltage range: 304V ~ 456V; Voltage unbalancedness ≤3%; allowable frequency fluctuation: ±5%																						
	Rated current(A)	5.4	7	10.7	15	20.5	27	35	38.5	46.5	62	76	92	113	157	180	214						
Braking unit	Built-in as standard										Need external												
Protection class	IP20																						
Cooling mode	Forced air convection cooling																						
Power(kW)	132	160	185	200	220	250	280	315	355	400	450	500	560	630	710	800							
Motor power(kW)	132	160	185	200	220	250	280	315	355	400	450	500	560	630	710	800							
Output	Voltage (V): Three-phase 0 to rated input voltage																						
	Rated current (A)	250	300	340	380	420	470	540	600	660	730	840	900	950	1160	1300	1460						
Overload capacity : 150% 1 minute; 180% 20 seconds,																							
Input	Rated voltage/frequency :Three-phase 380V~440V; 50Hz/60Hz																						
	Max. voltage range: 304V~456V; Voltage unbalancedness ≤3%; allowable frequency fluctuation: ±5%																						
	Rated current (A)	256	307*	345*	385*	430*	480*	548*	610*	670*	740*	850*	910*	960*	1170*	1310*	1470*						
Braking unit	Need external																						
Protection class	IP20																						
Cooling mode	Forced air convection cooling																						

* NE300-4T1600G-F and above products are equipped with in-built DC reactor as standard.

- NE300-4T□□□PB Three-phase 400V Variable torque/normal-duty application

Power (kW)	2.2	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132							
Motor power (kW)	2.2	4	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110	132							
Output	Voltage (V)	Three-phase 0 to rated input voltage																					
	Rated current (A)	6	9	13	17	25	32	37	45	60	75	90	110	150	176	210	250						
Input	Overload capacity : 120% 1 minute; 150% 1 second,																						
	Rated voltage/frequency :Three-phase 380V~440V; 50Hz/60Hz																						
	Max. voltage range: 304V ~ 456V; Voltage unbalancedness \leqslant 3%; allowable frequency fluctuation: \pm 5%																						
	Rated current(A)	7	10.7	15	20.5	27	35	38.5	46.5	62	76	92	113	157	180	214	256						
Braking unit	Built-in as standard										Need external												
Protection class	IP20																						
Cooling mode	Forced air convection cooling																						
Power(kW)	160	185	200	220	250	280	315	355	400	450	500	560	630	710	800	900							
Motor power(kW)	160	185	200	220	250	280	315	355	400	450	500	560	630	710	800	900							
Output	Voltage (V): Three-phase 0 to rated input voltage																						
	Rated current (A)	300	340	380	420	470	540	600	660	730	840	900	950	1160	1300	1460	1640						
Input	Overload capacity : 120% 1 minute; 150% 1 second																						
	Rated voltage/frequency :Three-phase 380V~440V; 50Hz/60Hz																						
	Max. voltage range: 304V~456V; Voltage unbalancedness \leqslant 3%; allowable frequency fluctuation: \pm 5%																						
	Rated current (A)	307	345*	385*	430*	480*	548*	610*	670*	740*	850*	910*	960*	1170*	1310*	1470*	1650*						
Braking unit	Need external																						
Protection class	IP20																						
Cooling mode	Forced air convection cooling																						

* NE300-4T1850P-F and above products are equipped with external DC reactor as standard.

3. Product Installation

3.1 NE200 Product Outline, Mounting Dimension (Unit: mm)




Fig.3-1 Product Outline, Mounting Dimension Schematic diagram

Note: NE200 series support 35mm DIN-rail mounting.

Inverter Model	H	W	D	H1	A	B	d
NE200-2S0004GB	150	83	120	166	65	153	5
NE200-2S0007GB							
NE200-2S0015GB							
NE200-4T0007G/0015PB							
NE200-4T0015G/0022PB							
NE200-4T0022GB-M							
NE200-2S0022GB	200	120	140	215	98	202	5
NE200-4T0022G/0040PB							
NE200-4T0040G/0055PB							
NE200-2S0004GB							

Note:

-M means compact model

3.2 NE300 Product Outline, Mounting Dimension (Unit: mm)




Fig.3-2 Product Outline, Mounting Dimension Schematic diagram

Inverter Model	H	W	D	H1	A	B	d
NE300-4T0015G/0022PB NE300-4T0022G/0040PB NE300-4T0040G/0055PB	210	133	180	238	108	225	7
NE300-4T0055G/0075PB NE300-4T0075G/0110PB NE300-4T0110G/0150PB	258	155	180	285	120	270	7
NE300-4T0150G/0185PB NE300-4T0185G/0220PB NE300-4T0220G/0300PB	310	192	186	340	150	323	7
NE300-4T0300G/0370P NE300-4T0370G/0450P	425	270	200	450	200	430	7
NE300-4T0450G/0550P NE300-4T0550G/0750P	535	320	248	560	240	540	9
NE300-4T0750G/0900P NE300-4T0900G/1100P NE300-4T1100G/1320P	640	380	248	665	240	640	9

Inverter Model	H	W	D	H1	A	B	d
NE300-4T1320G/1600P-U NE300-4T1320G/1600P-D NE300-4T1600G/1850P-U NE300-4T1600G/1850P-D	710	465	355	750	380	719	11
NE300-4T1850G/2000P-U NE300-4T1850G/2000P-D NE300-4T2000G/2200P-U NE300-4T2000G/2200P-D NE300-4T2200G/2500P-U NE300-4T2200G/2500P-D NE300-4T2500G/2800P-U NE300-4T2500G/2800P-D	859	550	385	900	440	868	11
NE300-4T1600G/1850P-F NE300-4T1850G/2000P-F NE300-4T2000G/2200P-F NE300-4T2200G/2500P-F	1400	400	400	1400	460	1270	13
NE300-4T2500G/2800P-F NE300-4T2800G/3150P-F NE300-4T3150G/3550P-F	1600	500	420	1600	560	1460	13
NE300-4T3550G/4000P-F NE300-4T4000G/4500P-F NE300-4T4500G/5000P-F NE300-4T5000G/5600P-F	1800	780	500	1800	840	1630	13
NE300-4T5600G/6300P-F NE300-4T6300G/7100P-F NE300-4T7100G/8000P-F NE300-4T8000G/9000P-F	2000	1000	700	2000	—	—	—
NE300-4T9000G-F	1800	<u>1560*</u>	500	1800	—	—	—

Note:

-U means input lines come from upside and output lines come out downside.

-D means input lines come from downside and output lines come out downside.

-F means freestanding models

* This model consisting of two separate models, 1560 is the net dimension

without mounting distance. **Must keep ≥ 200** mounting distance between them.

3.3 Operating keypad panel outline and mounting dimensions (Unit: mm)





Fig.3-3 Operating Panel Outline and Mounting Dimension

3.4 Keypad holder outline and mounting dimensions

NEF-KB01 is the mounting tray when the operation panel is to install on the electric control cabinet. The outline and dimensions are as follows:(Unit: mm):



Keypad tray dimensions

Keypad tray hole size

Fig.3-4 Operating Panel Outline and Mounting Dimension

4. Wiring of Inverter

4.1 Terminal Wiring of NE200




Fig. 4-1 Terminal Wiring (0022GB~0040GB)

4.1.1 Functions of Control Circuit Terminals

Standard configuration of control circuit terminals

Type	Terminal	Terminal function	Technical specification
Digital input & output	X1~X5	Multi-functional input terminals 1~5	Optical-isolator input Frequency range: 0~200Hz Voltage range: 0~12V
	Y1	Open collector output	Optical-isolator output maximum output current: 50mA Output voltage range: 0~24V
	GND	Terminal ref. grounding	
	24V	24V	24V±5%, Maximum load :200mA, with overload and short circuit protection
Analog input	10V	Analog input reference voltage	Open circuit voltage up to 11V; Maximum output 30mA
	AI1	Analog input channel 1	Input Voltage range: 0~10V Input impedance: 100kΩ
	AI2	Analog input channel 2	Input Voltage range: 0~10V Input impedance: 100kΩ Input current range: 0~30mA Current Input impedance: 500Ω, 0~20mA or 0~10V analog input can be selected through DIP switch SW1
	GND	Terminal ref. grounding	
Analog output	AO	Analog output 1	0~20mA: Allowed load impedance 200~500Ω 0~10V: Allowed load impedance ≥1kΩ. With SC protection; 0~20mA or 0~10V analog output can be selected through DIP switch SW2
	GND	Analog grounding	
Relay output	TA/TB/TC	Relay output 1	TA—TB: NC; TA—TC: NO Contact capacity: 250VAC/1A, 30VDC/1A

Type	Terminal	Terminal function	Technical specification
RS485	485+	485 differential positive	Rate: 1200/2400/4800/9600/19200/38400bps; Max. parallel 127 No.s; SW3 select adapted resistor; Max. Length 500m. (twisted shielding cable)
	485-	485 differential negative	
	GND	485 shielding grounding	Internal isolated with COM





Fig.4-2 Arrangement of Control Circuit Terminals

4.2 Terminal Wiring of NE300




Fig.4-3 Terminal Wiring (0220G/0300PB as example)

4.2.1 Functions of Control Circuit Terminals

Standard configuration of control circuit terminals

Type	Termina	Terminal function	Technical specification
Digital input	X1 ~ X3	Multi-functional input terminals 1~3	Optical-isolator input Frequency range: 0~200Hz Voltage range: 0~24V
	X4 X5	Multi-functional input or Single pulse input 4, 5	Multi-functional input: same as X1~X3 Single Pulse input: 0.1Hz~50kHz Voltage range: 0~24V
	COM	multi-functional input terminals common end	Internal isolated with GND
Digital output	24V	24V	24V±5%, Maximum load :200mA, with overload and short circuit protection
	Y1	Open collector output 1	Optical-isolator output maximum output current: 50mA Output voltage range: 0~24V
	DO	Open collector or high speed pulse output	Output frequency: 0~50kHz Open collector same as Y1
	COM	Open collector output common end	Internal isolated with GND
Analog input	10V	Analog input reference voltage	Open circuit voltage up to 11V; Internal isolated with com; Maximum load 30mA, with overload and short circuit protection
	AI1	Analog input channel 1	Input Voltage range: 0~10V Input impedance: 100kΩ

Type	Termina	Terminal function	Technical specification
	AI2	Analog input channel 2	Input Voltage range: 0~10V Input impedance: 100kΩ Input current range: 0~30mA Current Input impedance: 500Ω, 0~20mA or 0~10V analog input can be selected through DIP switch SW1
	GND	Analog grounding	Internal isolated with COM
Analog output	AO1	Analog output 1	0~20mA: Allow output impedance 200~500Ω 0~10V: Allowed output impedance ≥10kΩ. With SC protection; 0~20mA or 0~10V analog output can be selected through DIP switch SW2
	GND	Analog grounding	Internal isolated with COM
Relay output	TA/TB/ TC	Relay output 1	TA—TB: NC; TA—TC: NO Contact capacity: 250VAC/1A, 30VDC/1A
RS485	485+	485 differential positive	Rate: 1200/2400/4800/9600/19200/38400bps; Max. parallel 127 No.s; SW3 select adapted resistor; Max. Length 500m. (twisted shielding cable)
	485-	485 differential negative	
	GND	485 shielding grounding	Internal isolated with COM




Fig.4-4 Arrangement of Control Circuit Terminals

5. Operation and Display




Fig.5-1 Operation Panel Diagram

5.1 Keyboard button description

Table 5-1 Keyboard keys description

Keys	Name	Function
PRG	Programming key	Entry and exit of primary menu
ENTER	Confirmation key	Enter the next level menu or confirm the data setting
^	Increase key	Increase of the value or function code

v	Decrease key	Decrease of the value or function code
>>	Shift key	Select the to be displayed parameters in turn under stop interface or running interface; Choose the to be modified digits when setting parameters.
RUN	Running key	Run the inverter under keypad operation mode.
STOP	Stop/reset	Stop the inverter at running status; Reset operation in the fault alarm status. Its function is limited to setting of code FE.02.
Knob	Potentiometer	Adjust setting value when potentiometer is set up as input.

5.2 Instruction of function code viewing and modification

The operation panel of the NE200&300 inverter adopts three levels menu structure to carry out operations such as parameter setting. The three levels are:

1. Groups of function code (level-1 menu)
2. Function code (level-2 menu)
3. Function code setup value(level-3 menu)

Note:

At level 3 menu, pressing PRG key or ENTER key can return to level-2 menu. The difference between them is that: Pressing ENTER will save the setup and return to the level 2 menu and then automatically shift to the next function code; while pressing PRG key will directly return to level 2 menu without saving the parameter, and stay at current function code.

Below is the example of modifying the function code F9.01 from 10.00Hz to 20.00Hz. (The number of bigger font size refers to the blinking digit),




Fig.5-2 Example of 3 levels menu operating

At level-3 menu, if the parameter has no blinking digit, it indicates that this function code cannot be modified. The possible reasons include:

- 1) The function code is an unchangeable parameter, such as actual detection parameter, running record parameter, etc.
- 2) The function code cannot be modified in running status. It can be modified only after the inverter running is stopped.

6. Run the motor

Operations	Details
Before power-on	<p>Check:</p> <p>No operating signal.</p> <p>The motor has been connected.</p> <p>1 phase 220V/ 3 phase 380V input power has been connected correctly.</p>
The inverter is powered on	Confirm the inverter displays the correct operating mode on power -up. Reset the drive if the operation mode is incorrect. Contact your supplier if problem still exist.
G/P model selection	<p>FP.05=0 Type G</p> <p>FP.05=1 Type P</p>
Set max, upper &lower limit frequency	<p>F0.10 Basic frequency</p> <p>F0.11 Max frequency</p> <p>F0.12 Freq. upper limit</p> <p>F0.13 Freq. lower limit</p>
Set control mode	<p>F0.01=0: Sensorless vector control-1</p> <p>F0.01=1: Sensorless vector control-2</p> <p>F0.01=2: Vector control with encoder (NE300 only)</p> <p>F0.01=3: V/F control</p>
Set acceleration and deceleration time	<p>F0.19 Acceleration time (s)</p> <p>F0.20 Deceleration time (s)</p>
Set parameters on the motor nameplate	<p>F5.00 motor type</p> <p>F5.01 Poles of motor</p> <p>F5.02 Rated power of motor (KW)</p> <p>F5.03 Rated current of motor (A)</p> <p>F5.04 Rated speed of rotation of motor (RPM)</p>
Auto-tuning of motor	<p>F5.10=1 (static auto-tuning) or</p> <p>F5.10=2 (rotating auto-tuning, must unload) operate the motor via keypad to perform the auto-tuning.</p>
Run the motor	<p>Press Run button to run the motor.</p> <p>Increase or decrease the speed with keypad knob.</p>

7. List of Parameters

Attention:

“○”means the parameter can be changed during running.

“×”means the parameter cannot be changed during running;

“*” means the parameter is detected value or fixed value and not changeable.

“-” means manufacturer parameter and the users have no access to it.

(2) indicates this parameter is only for NE200

(3) indicates this parameter is only for NE300

F0: Basic function group

Code	Description	Setting range	Default	Modify	Modbus Address
F0.00	(2) Reserved	Reserved	Reserved	-	0100H
F0.00	(3) Drive type display	0~1	0	×	0100H
F0.01	(2) Control mode	0: No vector Sensor vector control-1 1: No vector Sensor vector control-2 2: Reserved 3: V/F control	0	×	0101H
	(3) Control mode	0: No vector Sensor vector control-1 1: No vector Sensor vector control-2 2: Vector control with encoder 3: V/F control	0	×	0101H
F0.02	Run command control mode	0: Keypad control	0	○	0102H
		1: Terminal control			
		2: Communication control			
F0.03	Frequency reference1 (Freq. ref.1)	0: Digital reference (keypad, terminal up/down) 1: AI1 2: AI2	0	○	0103H

Code	Description	Setting range	Default	Modify	Modbus Address
		3: PULSE setup 4: Communication 5:MS (Multi-step) Speed 6: PLC 7: PID 8: Keypad potentiometer			
F0.04	Frequency reference2 (Freq. ref.2)	1: AI1 2: AI2 3: PULSE setup 4: Communication 5:MS (Multi-step) Speed 6: 7: Reserved Reserved 8: Keypad potentiometer	1	○	0104H
F0.05	Frequency setting selection	0:Freq. ref.1 1:Freq. ref.2 2: Freq. ref.1+ Freq. ref.2 3: Switch between Freq. ref.1 & Freq. ref.2 by terminal 4: Switch between (Freq. ref.1+ Freq. ref.2) & Freq. ref.1 by terminal 5:MIIN (Freq. ref.1, Freq. ref.2) 6:MAX (Freq. ref.1, Freq. ref.2)	0	○	0105H
F0.06	UP/DOWN Preset freq.	0~ Max frequency	50.00Hz	○	0106H
F0.07	Terminal UP/DOWN rate	0.01~ 50.00Hz/s	1.00Hz/s	○	0107H
F0.08	UP/DOWN function source select	0: Keypad and terminal 1: Keypad 2: Terminal	1	○	0108H
F0.09	UP/DOWN data saving	0: Be saved in power failure	0	○	0109H

Code	Description	Setting range	Default	Modify	Modbus Address
	selection	1: Be saved in power failure 2: Be cleared to 0 after stop			
F0.10	Basic frequency	0.10~550.0Hz	50.00Hz	x	010AH
F0.11	Max frequency	MAX[50.00Hz, Freq. upper limit, Reference frequency]~550.0Hz	50.00Hz	x	010BH
F0.12	Freq. upper limit	Freq. lower limit ~ Max frequency	50.00Hz	x	010CH
F0.13	Freq. lower limit	0.00~Frequency upper limit	0.00Hz	x	010DH
F0.14	Max output voltage	110~440V	Depend on model	x	010EH
F0.15	Carrier freq.	1.0~16.0KHz	Depend on model	o	010FH
F0.16	Carrier freq. auto-adjust	0: disable 1: able	0	o	0110H
F0.17	Keypad direction	0: Forward 1: Reverse	0	o	0111H
F0.18	Motor wiring direction	0: Positive sequence 1: Reversed sequence	0	x	0112H
F0.19	Acc. time1	0.1~3600s	Depend on model	o	0113H
F0.20	Dec. time1	0.1~3600s	Depend on model	o	0114H

Group F1: Start and stop control

Code	Description	Setting range	Default	Modify	Modbus Address
F1.00	②Start mode	0: Start directly 1: DC injection brake first and then start at start freq.	0	o	0200H

Code	Description	Setting range	Default	Modify	Modbus Address
	③ Start mode	0: Start directly 1: DC injection brake first and then start at start freq. 2: Speed tracking and start	0	○	0200H
F1.01	Start freq.	0.10~60.00Hz	0.50Hz	○	0201H
F1.02	Start freq. hold time	0.0~10.0s	0.0s	○	0202H
F1.03	② DC brake current at start	G: 0.0~100.0% rated current	0.00%	○	0203H
F1.03	③ DC brake current at start	G: 0.0~100.0% rated current	0.00%	○	0203H
		P: 0.0~80.0% rated current			
F1.04	DC brake time at start	0.0~30.0s	0.0s	○	0204H
F1.05	Acc./Dec. mode	0: Linear 1: S-curve	0	○	0205H
F1.06	Time of S-curve initial stage	10.0~50.0% (Acc./ Dec. time) F1.06+F1.07≤90%	30.00%	○	0206H
F1.07	Time of S-curve rising stage	10.0~80.0% (Acc./ Dec. time) F1.06+F1.07≤90%	40.00%	○	0207H
F1.08	Stop mode	0: Deceleration to stop 1: Coast to stop 2: Deceleration +DC braking	0	×	0208H
F1.09	DC brake trigger frequency at stop	0.00~550.0Hz	0.00Hz	○	0209H
F1.10	DC brake waiting time at stop	0.00~10.00s	0.00s	○	020AH
F1.11	② DC brake current at stop	0.0~100% rated current	0.00%	○	020BH

Code	Description	Setting range	Default	Modify	Modbus Address
	③ DC brake current at stop	Type G: 0.0~100.0% rated current Type P: 0.0~80.0% rated current	0.00%	<input type="radio"/>	020BH
F1.12	DC brake time at stop	0.0~30.0s	0.0s	<input type="radio"/>	020CH
F1.13	Energy consumption brake validity	0: Disabled 1: Enabled	0	<input type="radio"/>	020DH
F1.14	Energy consumption brake action voltage	380V: 650~750V 220V: 360~390V	700V 380V	<input type="radio"/>	020EH
F1.15	Power failure and fault restart	0: Disable 1: Enabled for power failure 2: Enabled for fault 3: Enabled for both Note: Power recovery restart is only valid for terminal 2-wires mode. Fault restart is invalid for under-voltage fault.	0	<input type="radio"/>	020FH
F1.16	Waiting time for restart	0.0~3600s	2.0s	<input type="radio"/>	0210H
F1.18	③ Rotational speed tracking direction inspection	0: Disable 1: Enable	0	<input type="radio"/>	0212H
F1.19	③ Rotational speed tracking direction inspection time	10~1000ms	50ms	<input type="radio"/>	0213H

Group F2: Auxiliary running function

NE200&300 Quick Start Guide

Code	Description	Setting range	Default	Modify	Modbus Address
F2.00	Jog running freq.	0.0~50.00Hz	5.00Hz	○	0300H
F2.01	Jog Acc. time	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0301H
F2.02	Jog Dec. time	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0302H
F2.03	Acc. time2	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0303H
F2.04	Dec. time2	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0304H
F2.05	Acc. time3	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0305H
F2.06	Dec. time3	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0306H
F2.07	Acc. time4	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0307H
F2.08	Dec. time4	(2) 0.1~360.0s (3) 0.0~3600.0s	6.00s (2) 20.0s (3)	○	0308H
F2.09	(2) Reserved	Reserved	Reserved	Reserved	0309H
	(3) Skip freq. 1	0.00~320.0Hz	0.00Hz	×	0309H
F2.10	(3) Skip freq. 2	0.00~320.0Hz	0.00Hz	×	030AH
F2.11	Skip freq. amplitude	0.00~15.00Hz	0.00Hz	×	030BH
F2.12	Anti-Reverse control	0: Reverse rotation allowed 1: Reverse rotation not allowed	0	○	030CH
F2.13	Fwd/ Rev switch dead-zone time	0.0~3600s	0.0s	○	030DH
F2.14	Freq. lower-limit treatment	0: Run with frequency lower limit 1: Zero frequency operation	0	×	030EH
F2.15	Reserved	Reserved	0	×	
F2.16	(3)	0: Disable	1	○	0310H

Code	Description	Setting range	Default	Modify	Modbus Address
	Energy-saving control select	1: Enable			
F2.17	AVR Function	0: Disabled 1: Enabled 2: Disabled only at speed-down	2	x	0311H
F2.18	Over modulation	0: Enabled 1: Disabled	1	x	0312H
F2.19	(3)Droop control	0.00~10.00Hz	0.00Hz	o	0313H
F2.20	Fan control mode	0: Auto mode 1: Always Running	0	x	0314H
F2.21	Instant-power-failure treatment	0: Disabled ②1: Drop frequency (Reserved) ③1: Drop frequency 2: Stop directly	0	o	0315H
F2.22	Instant-power-failure freq. drop point	210~600V	380V:420V 220V:230V	o	0316H
F2.23	Instant-power failure freq. drop rate	1~800	400	o	0317H
F2.24	Motor speed display ratio	0.00~500.0%	100.00%	o	0318H
F2.25	UP/DOWN drop to minus frequency	0: Enabled 1: Disable	1	o	0319H
F2.26	ENTER key function	0: No special action 1: FWD/REV switching 2: RUN for forward; Enter for reverse; STOP for stop 3: Jog running	0	o	031AH
F2.27	Freq. resolution	0: 0.01Hz 1: 0.1Hz	0	x	031BH
F2.28	Acc./Dec. time unit	0: 0.1s 1: 0.01s	1 ②0 ③	x	031CH

Code	Description	Setting range	Default	Modify	Modbus Address
F2.29	High freq. modulation mode	0: Asynchronous modulation 1: Synchronous modulation	0	x	031DH
F2.31	IO output Freq. baseline select while vector control	0: According to the Freq. after ACC/DEC speed 1: According to the current value	0	o	031FH
F2.32	PWM modulation mode	0: uplink 16Hz discrete modulation mode (5-stage mode), downlink 12Hz continuous modulation mode (7-stage mode) 1: fixed as z continuous modulation mode (7-stage mode)	0	o	0320H
F2.33	Threshold value of Zero Freq. running	0.00~550.0Hz	0.00Hz	o	0321H
F2.34	Range between start Freq. and threshold value of Zero Freq.	0.00~550.0Hz	0.00Hz	o	0322H
F2.35	Synchronous motor IQ filter	0: with filter 1: without filter	0	o	0323H
F2.36	Voltage modulation coefficient of synchronous motor with weak magnetic field	0.0~120.0%	105.0%	o	0324H

Group F3: Vector Control Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
F3.00	Speed loop proportional gain 1	1~3000	1000	○	0400H
F3.01	Speed loop integral time 1	1~3000	300	○	0401H
F3.02	Switching frequency 1	0.0~60.00Hz	5.00Hz	○	0402H
F3.03	Speed loop proportional gain 2	1~3000	800	○	0403H
F3.04	Speed loop integral time 2	1~3000	200	○	0404H
F3.05	Switching frequency 2	0.0~60.00Hz	10.00Hz	○	0405H
F3.06	Speed loop filter time constant	0~500ms	2ms (2) 3ms (3)	○	0406H
F3.07	Current loop proportional coefficient	0~6000	3000	○	0407H
F3.08	Current loop integral coefficient	0~6000	1500	○	0408H
F3.09	VC Slip compensation	0.0~200.0%	100.00%	○	0409H
F3.10	(2) Torque control	0:Torque control Disabled 1:Torque digital setting(F3.11) 2:AI1 3:AI2 4:Reserved 5:communication 6:keypad potentiometer	0	○	040AH
		0:Torque control Disabled 1:Torque digital setting(F3.11) 2:AI1 3:AI2			

Code	Description	Setting range	Default	Modify	Modbus Address
		4:Pulse 5:communication 6:keypad potentiometer			
F3.11	Torque digital setting	0.0~200.0%	50.00%	○	040BH
F3.12	Torque control speed limit	0: digital setting(F3.13) 1: AI1 2: AI2 3: PULSE communication 5: keypad potentiometer	4: 0	○	040CH
F3.13	Torque control speed limit digital setting	0.00~550.0Hz	50.00Hz	○	040DH
F3.14	③Encoder pulse number	1~9999	1000	○	040EH
F3.15	③Motor and PG reduction ratio	0.010~50.000	1.000	○	040FH
F3.16	③PG direction	0: Forward Reverse	1: 0	○	0410H
F3.17	ACC/DEC limit controlled by PG	0: Limited 1: No limited	0	○	0411H
F3.18	SVC speed calculation filter	0~15	5	○	0412H
F3.19	SVC mode	0: Mode1 1: Mode2	0	○	0413H
F3.20	SVC mode2 flux weaken coefficient	20~500%	100%	○	0414H
F3.21	Flux weaken control selection	0: Disable Enable	1: 0	○	0415H
F3.22	Torque limit compensation coefficient while	60.0~300.0%	85% 200% ② ③	○	0416H

Code	Description	Setting range	Default	Modify	Modbus Address
	constant power output				
F3.23	Reserved	Reserved	Reserved	Reserve d	
F3.24	Torque ref. terminal single modulation	0.0~10%	0.00%	○	0418H
F3.25	Torque ref. terminal total modulation	0.0~100%	50%	○	0419H
F3.26	Torque limit in vector control mode	0~300.0%	150.0%	○	041AH
F3.27	Torque boost cut-off frequency in torque control mode	0.00~15.00Hz	12.00Hz	○	041BH
F3.28	Torque boost amount in torque control mode	0.0~20.0%	15.0%	○	041CH
F3.31	Synchronous motor initial position detection	0: Do not detect 1: Detect in power-on first run 2: Detect every time	2	○	041FH
F3.32	Synchronous motor initial position detection current	50~120%	90%	○	0420H
F3.33	Initial position detection pulse width	0~1200us	0	○	0421H
F3.34	Initial position detection pulse width actual value	0~1200us	0	*	0422H
F3.35	Synchronous motor braking torque limit	0.0~300.0%	150.0%	○	0423H
F3.36	Synchronous motor flux weaken mode	0: Flux weaken mode is invalid	0	○	0424H

Code	Description	Setting range	Default	Modify	Modbus Address
		1: Flux weaken mode is valid			
F3.37	Max flux weaken current	0~100.0%	50%	○	0425H
F3.38	Flux weaken regulation proportional coefficient	0~3000	500	○	0426H
F3.39	Flux weaken regulation integration coefficient	0~3000	800	○	0427H
F3.40	Synchronous motor low speed Min. current	0~100%	30%	○	0428H
F3.41	Synchronous motor low speed carrier frequency	1.0~16.0KHz	2.0KHz	○	0429H
F3.42	Synchronous motor Min excitation current	-100.0~100.0%	0.0%	○	042AH
F3.43	②V/F Start switching frequency	0~50.00Hz	0.00Hz	○	042BH
F3.44	Synchronous motor position evaluating low speed filter	2~100	40	○	042CH
F3.45	Synchronous motor position evaluating high speed filter	2~100	15	○	042DH

Group F4: V/F Control Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
F4.00	V/F curve setting	0: Constant torque load V/F 1: 2.0 power decreasing torque 2: 1.5 power decreasing torque	0	x	0500H
		3: 1.2 power decreasing torque 4: Multiple dots V/F			
F4.01	V/F freq. F1	0.0~F4.03	10.00Hz	x	0501H
F4.02	V/F voltage V1	0.0~100.0%	20.00%	x	0502H
F4.03	V/F freq. F2	F4.01~F4.05	25.00Hz	x	0503H
F4.04	V/F voltage V2	0.0~100.0%	50.00%	x	0504H
F4.05	V/F freq. F3	F4.03~F0.10	40.00Hz	x	0505H
F4.06	V/F voltage V3	0~100.0%	80.00%	x	0506H
F4.07	Torque boost	0.0%: Auto boost 0.1~30.0%: Manual boost	0.00%	o	0507H
F4.08	Manual torque boost cutoff point	0.00~60.00Hz	50.00Hz	o	0508H
F4.09	Slip compensation coefficient	0.0~200.0%	0.00%	o	0509H
F4.10	Slip compensation filtering time	0.01~2.55s	0.20s	o	050AH

Code	Description	Setting range	Default	Modify	Modbus Address
F4.11	V/F separation control voltage source	0: disabled 1: Digital setting (F4.12) 2: AI1 3: AI2 4: Pulse 5: communication	0	×	050BH
F4.12	V/F separation voltage digital setting	0V~max output voltage	38 0V	○	050CH
F4.13	V/F separation voltage rising time	0.0s~1000.0s	0.0s	○	050DH
F4.14	V/F oscillation suppression	0~500	Depends on model	○	050EH
F4.15	Vibration suppressor	0~10	2	○	050FH

Group F5: Motor Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
F5.00	motor type	0: Common asynchronous motor 1: Variable frequency asynchronous motor 2: PM motor	0	×	0600H
F5.01	Motor polarity number	2~56	4	×	0601H
F5.02	rated power	(2) 0.1~6553.5kW (3) 0.4~999.9kW	Depends on model	○	0602H

Code	Description	Setting range	Default	Modify	Modbus Address
F5.03	rated current	(2) 0.01~655.35A (3) 0.1~999.9A	Depends on model	○	0603H
F5.04	rated speed	(2) 0~65535RPM (3) 0~24000 RPM	Depends on model	○	0604H
F5.05	No-load current I0	(2) 0.01~655.35A (3) 0.1~999.9A	Depends on model	○	0605H
F5.06	(2) Stator resistance R1	1~65535mΩ	Depends on model	○	0606H
	(3) Stator resistance R1	1~65535mΩ(Drive rated power≤22kW) 0.1~6553.5mΩ(Drive rated power>22kW)	Depends on model	○	0606H
F5.07	(2) Leakage inductive reactance X	0.01~655.35mH	Depends on model	○	0607H
	(3) Leakage inductive reactance X	0.01~655.35mH(Drive rated power≤22kW) 0.001~65.535mH(Drive rated power>22kW)	Depends on model	○	0607H
F5.08	(2) Rotor resistance R2	1~65535mΩ	Depends on model	○	0608H
	(3) Rotor resistance R2	1~65535mΩ(Drive rated power≤22kW) 0.1~6553.5mΩ(Drive rated power>22kW)	Depends on model	○	0608H
F5.09	(2) Mutual Inductive reactance Xm	0.1~6553.5mH	Depends on model	○	0609H

Code	Description	Setting range	Default	Modify	Modbus Address
	③ Mutual Inductive reactance Xm	0.1~6553.5mH(Drive rated power≤22kW) 0.01~655.35mH(Drive rated power>22kW)	Depends on model	○	0609H
F5.10	Auto tune	0: No operation 1: Static tuning 2: Rotary tuning	0	×	060AH
F5.11	② Synchronous motor stator resistor Rs	1~65535mΩ	Depends on model	○	060BH
	③ Synchronous motor stator resistor Rs	1~65535mΩ(Drive rated power≤22kW) 0.1~6553.5mΩ(Drive rated power>22kW)	Depends on model	○	060BH
F5.12	② Synchronous motor D-axis inductance Ld	0.01~655.35mH	Depends on model	○	060CH
F5.12	③ Synchronous motor D-axis inductance Ld	0.01~655.35mH(Drive rated power≤22kW) 0.001~65.535mH(Drive rated power>22kW)	Depends on model	○	060CH
F5.13	② Synchronous motor Q-axis inductance Lq	0.01~655.35mH	Depends on model	○	060DH
	③ Synchronous motor Q-axis inductance Lq	0.01~655.35mH(Drive rated power≤22kW) 0.001~65.535mH(Drive rated power>22kW)	Depends on model	○	060DH

Code	Description	Setting range	Default	Modify	Modbus Address
F5.14	Synchronous motor counter EMF constant	0.0~6553.5v	300.0v	○	060EH

Group F6: Input terminals

Code	Description	Setting range	Default	Modify	Modbus Address
F6.00	Terminal Command mode	0: Two-wire mode 1 1: Two-wire mode 2 2: Three-wire mode 1 3: Three-wire mode 2	0	×	0700H
F6.01	X1 terminal Function selection	0: NULL 1: FWD 2: REV 3: RUN	1	×	0701H
F6.02	X2 terminal Function selection	4: F/R direction 5: HLD self-hold	2	×	0702H
F6.03	X3 terminal Function selection	6: FWD jog run (FJOG) 7: REV jog run (RJOG)	8	×	0703H
F6.04	X4 terminal Function selection	8: RESET 9: Freq. source switching	17	×	0704H
F6.05	X5 terminal Function selection	10: Terminal UP 11: Terminal DOWN	18	×	0705H
F6.06	③ X6 terminal Function selection ② AI1 terminal function	12: UP/DOWN setup clear 13: Coast to stop 14: DC brake 15: Acc./Dec. prohibit 16: Drive running prohibit	0	×	0706H

Code	Description	Setting range	Default	Modify	Modbus Address
	selection	17: Multi-step terminal 1 18: Multi-step terminal 2 19: Multi-step terminal 3 20: Multi-step terminal 4 21: torque control disable			
F6.07	(3) X7 terminal Function selection (2) AI2 terminal function selection	22: Acc./Dec. time selector 1 23: Acc./Dec. time selector 2 24: Running pause normally open 25: Running pause normally closed 26: External fault normally open 27: External fault normally closed	0	x	0707H
F6.08	(2) Reserve (3) X8 terminal function selection	28: Run command switch to terminal 29: Run command switch to keypad 30: External stop terminal; same to STOP key in keypad control mode. 31: Reserved 32: PLC status reset 33: Wobble freq. pause 34: Wobble freq. status reset	Reserved	x	0708H
F6.09	(2) Reserve (3) AI1 terminal function selection		Reserved	x	
					0709H

Code	Description	Setting range	Default	Modify	Modbus Address
		35: PID pause 36: PID parameters switching 37: PID direction reversion; Active this terminal to reverse PID direction set by F8.04. 38: Timing drive input 39: Counter signal input 40: Counter clear 41: Actual length clear 42: FWD running (FWD NC) 43: REV running (REV NC) 44: HLD (Normally open) 45: Increase torque 46: Torque increment clear 47: Decrease torque 48: One key recover user parameters(Valid in stop state) 49~56: Reserved 57: Pulse input (Take X4 in case 2 inputs)			
F6.10	Analog Nonlinear Selection	0: none 1: AI1 2: AI2 3: Pulse	0	x	070AH
F6.11	AI1 Min. input	0.00~F6.13	0.00V	o	070BH
F6.12	AI1 Min. input corresponding setup	-200.0~200.0%	0.00%	o	070CH

Code	Description	Setting range	Default	Modify	Modbus Address
F6.13	AI1 Max. input	F6.11~10.00V	10.00V	○	070DH
F6.14	AI1 Max. input corresponding setup	-200.0~200.0%	100.00%	○	070EH
F6.15	AI1 input filter time	0.01~50.00s	0.05s	○	070FH
F6.16	AI2 Min. input	0.00~F6.18	0.00V	○	0710H
F6.17	AI2 Min. input corresponding setup	-200.0~200.0%	0.00%	○	0711H
F6.18	AI2 Max. input	F6.16~10.00V	10.00V	○	0712H
F6.19	AI2 Max. input corresponding setup	-200.0~200.0%	100.00%	○	0713H
F6.20	AI2 input filter time	0.01~50.00s	0.05s	○	0714H
F6.21	PULSE Min. input	0.00~F6.23	0.00kHz	○	0715H
F6.22	PULSE Min. input corresponding setup	-200.0%~200.0%	0.00%	○	0716H
F6.23	PULSE Max. input	F6.21~50.00kHz	50.00kHz	○	0717H
F6.24	PULSE Max. input corresponding setup	-200.0%~200.0%	100.00%	○	0718H
F6.25	Pulse filter time	0.01~50.00s	0.05s	○	0719H
F6.26	Terminal up/down initial increment	0.00~10.00Hz	0.01Hz	○	071AH
F6.27	Freq. ref.2 datum	0: Max. freq. 1: Freq. ref.1	0	○	071BH

Code	Description	Setting range	Default	Modify	Modbus Address
F6.28	Delay duration of X1 terminal close	0.0~100.0s	0.0s	○	071CH
F6.29	Delay duration of X1 terminal open	0.0~100.0s	0.0s	○	071DH
F6.30	Delay duration of X2 terminal close	0.0~100.0s	0.0s	○	071EH
F6.31	Delay duration of X2 terminal open	0.0~100.0s	0.0s	○	071FH
F6.32	Pos. and Neg. logic terminal X 1	Pos. logic of Xi terminal: Be valid while connecting between Xi and COM. Neg. logic of Xi terminal: Be valid while disconnecting between Xi and COM. Units: Logic of X1 terminal Tens: Logic of X2 terminal Hundreds: Logic of X3 terminal Thousands: Logic of X4 terminal	0000	×	0720H
F6.33	② Pos. and Neg. logic terminal X 2	Units: Logic of X5 terminal Tens: Logic of AI1 terminal Hundreds: Logic of AI2 terminal	0000	×	0721H

Code	Description	Setting range	Default	Modify	Modbus Address
		Note: Terminal 24, 25, 26, 27, 42, 43, 44 and 49 are not impacted by this parameter.			
F6.33	③ Pos. and Neg. logic terminal X 2	Units: Logic of X5 terminal Tens: Logic of X6 terminal Hundreds: Logic of X7 terminal Thousands: Logic of X8 terminal Note: Terminal 24, 25, 26, 27, 42, 43, 44 and 49 are not impacted by this parameter.			0721H

Group F7: Output terminal

Code	Description	Setting range	Default	Modify	Modbus Address
F7.00	② Reserve	0: NULL 1: RUN 2: Freq. arrival(FAR) 3: Freq. level detection 1 (FDT1) 4: Freq. level detection 2 (FDT2) 5: Freq. detection when speed-up 6: Freq. detection when speed-down 7: Zero-speed running	Reserve	Reserve	0800H
	③ DO terminal output definition		0	○	0800H
F7.01	Y1 terminal output selection		1	○	0801H
F7.02	② Reserve	0: NULL 1: RUN 2: Freq. arrival(FAR) 3: Freq. level detection 1 (FDT1) 4: Freq. level detection 2 (FDT2) 5: Freq. detection when speed-up 6: Freq. detection when speed-down 7: Zero-speed running	Reserve	Reserve	0802H
	③ Y2 terminal output selection		0	○	0802H

Code	Description	Setting range	Default	Modify	Modbus Address
F7.03	Relay 1 (TA/TB/TC) output selection	8: Zero-speed 9: PLC circulation completion 10: Reserved 11: Ready for running (RDY) 12: Timing arrival 13: Counting arrival 14: Reserved 15: Preset torque value arrival 16: Drive fault output 17: Under voltage status output 18: Drive overload pre-warning 19: Fixed-length arrived, level signal 20: PID in dormancy 21: AI1>AI2 22: AI1<F7.16 23: AI1>F7.16 24: F7.16<AI1<F7.17 25: Frequency lower limit arrival 26: Multi-pumps system auxiliary pump control signal 27: Communication setting 28: Drive running time arrival 29: Running in FWD 30: Running in REV 31: Instantaneous power loss processing 32: Current arrival	16	○	0803H
F7.04	② Reserve		Reserve	Reserve	0804H
F7.04	③ Relay 2 (BRA/BRB/BRC) output selection		0	○	0804H

Code	Description	Setting range	Default	Modify	Modbus Address
F7.05	Freq. arrival (FAR) detection width	0.00~10.00Hz	2.50Hz	○	0805H
F7.06	Frequency detection value 1 (FDT1 level)	0.00~600.0Hz	5.00Hz	○	0806H
F7.07	Freq. detection lag1 (FDT1-lag)	0.00~10.00Hz	1.00Hz	○	0807H
F7.08	② Frequency detection value 2 (FDT2 level)	0.00~320.0Hz	5Hz	○	0808H
	③ Frequency detection value 2 (FDT2 level)	0.00~320.0Hz	25.00Hz	○	0808H
F7.09	Freq. detection lag2 (FDT2-lag)	0.00~10.00Hz	1.00Hz	○	0809H
F7.10	Up detection frequency	0.00~550.0Hz	50.00Hz	○	080AH
F7.11	Down detection frequency	0.00~550.0Hz	0.00Hz	○	080BH
F7.12	Torque detection reference	0.0~200.0%	100.00%	○	080CH
F7.13	Preset Counting arrival value	0~9999	0	○	080DH
F7.14	Preset Timing arrival value	0.0~6553.0s	0.0s	○	080EH
F7.16	AI1 compare threshold 1	0.00~10.00v	0.00v	○	0810H
F7.17	AI1 compare threshold 2	0.00~10.00v	0.00v	○	0811H
F7.18	Analog compare hysteresis error	0.00~30.00v	0.20v	○	0812H

Code	Description	Setting range	Default	Modify	Modbus Address
F7.19	②AO function definition ③AO1 output selection	0: NULL 1: Running freq. (0~max frequency) 2: Setting freq. (0~max frequency)	1	○	0813H
F7.20	②Reserve	3: Output current(0~2 times of drive rated current)	Reserve	Reserve	0814H
	③AO2 output selection	4: Output voltage (0~Max Voltage) 5: PID setup (0~10V) 6: PID feedback (0~10V) 7: Calibrating signal (5V) 8: Output torque (0~2 times of motor rated torque) 9: Output power (0~2 times of drive rated power)	0	○	0814H
F7.21	②Y1 function definition	10: Bus voltage (0~1000V) 11: 9: AI1 (0~10V) 12: AI2 (0~10V/4~20mA) 13: Pulse frequency 14: Communication setting 15: Reserve	0	○	0815H
	③DO output selection	16: Current output (0~2 time rated value)	0	○	0815H
F7.22	②AO output range selection	0: 0~10V/0~20mA	0	○	0816H
	③AO1 output range selection	1: 2~10V/4~20mA			0816H

Code	Description	Setting range	Default	Modify	Modbus Address
F7.23	② Reserve	Reserve	Reserve	Reserve	0817H
	③ AO2 output range selection	0: 0~10V/0~20mA 1: 2~10V/4~20mA	0	○	0817H
F7.24	② Gain of AO	1~200%	100%	○	0818H
	③ Gain of AO1				0818H
F7.25	② Reserve	Reserve	Reserve	Reserve	0819H
	Gain of AO2 ③	1~200%	100%	○	0819H
F7.26	② Y1 Max. output pulse freq.	Y1 Min. output pulse freq. ~ 50.00kHz	10.00kHz	○	081AH
	③ DO Max. output pulse freq.	DO Min. output pulse freq. ~ 50.00kHz			081AH
F7.27	② Y1 Min. output pulse freq.	0.00~Y1 Max. output pulse freq.	0.00kHz	○	081BH
	③ DO Min. output pulse freq.	0.00~DO Max. output pulse freq.	0.00kHz	○	081BH
F7.28	Auxiliary pump start lag time	0~9999s	0	○	081CH
F7.29	Auxiliary pump stop lag time	0~9999s	0	○	081DH
F7.30	② Y1 Max. output	0: 50.00KHz 1: 500.0Hz	0	×	081EH
	③ DO Max. output				081EH
F7.31	FDT/RUN signal Jog selection	0: Include Jog signal 1: Do not include Jog signal	0	×	081FH
F7.32	Running time arrival setup	0~65530Mins	0	○	0820H
F7.33	Running time arrival stop	0: Do not stop 1: Stop	0	○	0821H

Code	Description	Setting range	Default	Modify	Modbus Address
	selection				
F7.34	Ao1 4mA/2.00v adjustable datum	0.0~100.0%	20%	○	0822H
F7.35	② Reserve	Reserve	Reserve	Reserve	0823H
	③ Ao2 4mA/2.00v adjustable datum	0.0~100.0%	20%	○	0823H
F7.36	② Digital output terminal Pos./Neg. logic	Units: Logic of Y1 terminal Tens: Reserve Hundreds: Logic of Relay 1 Thousands: Reserve	0000	○	0824H
	③ Digital output terminal Pos./Neg. logic	Units: Logic of Y1 terminal Tens: Logic of Y2 terminal Hundreds: Logic of Relay 1 Thousands: Logic of Relay 2	0000	○	0824H
F7.37	Current reaches the upper limit	0.0~655.35A	0.0A	○	0825H
F7.38	Current upper limit check time	0.00~50.00s	0.00s	○	0826H
F7.39	Current reaches lower limit	0.0~655.35A	0.0A	○	0827H
F7.40	Current lower limit check time	0.00~50.00s	0.00s	○	0828H
F7.41	AO torque output range selection	0: 0~200% the rated torque of motor 1: -200~200% Motor rated torque output	0	○	0829H

Group F8: PID Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
F8.00	PID setup channel selection	0: PID digital setting (F8.02) 1: AI1 2: AI2 3: Pulse input 4: serial communication	0	○	0900H
F8.01	PID feedback channel selection	0: AI1 1: AI2 2: Pulse input 3: serial communication 4: AI1-AI2 5: AI1+AI2 6: MAX(AI1, AI2) 7: MIN(AI1, AI2)	1	○	0901H
F8.02	Analog PID digital setup	0.0~999.9	50	○	0902H
F8.03	Analog closed loop measuring range	1.0~999.9	100	○	0903H
F8.04	PID action direction	0: Positive 1: Negative	0	○	0904H
F8.05	PID proportional gain 1 (KP1)	0.1~9.9	1	○	0905H
F8.06	PID integration time 1	0~100s	10s (2) 3s (3)	○	0906H
F8.07	PID differential time 1	0.00~1.00s	0.00s	○	0907H
F8.08	PID proportional gain 2 (KP2)	0.1~9.9	1	○	0908H
F8.09	PID integration time 2	0.0~100.0s	10.0s	○	0909H

Code	Description	Setting range	Default	Modify	Modbus Address
F8.10	PID differential time 2	0.00~1.00s	0.00s	○	090AH
F8.11	PID parameters switching	0: No switching, use the first group parameters 1: switching by terminal 2: auto-switching by deviation	0	○	090BH
F8.12	PID parameter switching Deviation 1	0.0~999.9	20	○	090CH
F8.13	PID parameter switching Deviation 2	0.0~999.9	80	○	090DH
F8.14	PID delay time constant	0.0~100.0s	0.0s	○	090EH
F8.15	Deviation limit	0.0~999.9	0.2	○	090FH
F8.16	PID output positive limit	(2) 0.0~320.0Hz (3) 0.0~600.0Hz	50.00Hz	○	0910H
F8.17	PID output negative limit	0.00~550.0Hz	0.00Hz	○	0911H
F8.18	PID preset freq.	0.00~550.0Hz	0.00Hz	✗	0912H
F8.19	Hold time of PID preset frequency	0.0~3600s	0.0s	✗	0913H
F8.20	Enable dormancy	0: Disabled 1: Enabled	0	✗	0914H
F8.21	Dormancy delay	0~999s	120s	○	0915H
F8.22	Dormancy threshold	0.0~320.0Hz	20.0Hz	○	0916H
F8.23	Awaken threshold	0.0~100.0% (relative to pre-set value)	80.00%	○	0917H
F8.24	PID feedback offline detection	0.0~100.0% (relative to feedback)	0.0%	○	0918H

Code	Description	Setting range	Default	Modify	Modbus Address
	range	measuring range, 0.0% no detection)			
F8.25	PID feedback offline detection time	0.0~50.0s	2.0s	○	0919H
F8.26	PID feedback offline detection Min. Freq.	0.00~50.00Hz	10.00Hz	○	091AH

Group F9: Multi-step speed and PLC

Code	Description	Setting range	Default	Mod ify	Modbus Addres s
F9.00	Multi-step freq.1	0.00~Max frequency	5.00 Hz	○	0A00H
F9.01	Multi-step freq.2	0.00~Max frequency	10.00 Hz	○	0A01H
F9.02	Multi-step freq.3	0.00~Max frequency	15.00 Hz	○	0A02H
F9.03	Multi-step freq.4	0.00~Max frequency	20.00 Hz	○	0A03H
F9.04	Multi-step freq.5	0.00~Max frequency	30.00 Hz	○	0A04H
F9.05	Multi-step freq.6	0.00~Max frequency	40.00 Hz	○	0A05H
F9.06	Multi-step freq.7	0.00~Max frequency	50.00 Hz	○	0A06H
F9.07	PLC running mode	0: Single cycle 1: Single cycle and hold final value 2: Continuous cycle	2	×	0A07H
F9.08	PLC restarting mode after interrupt	0: Restart from first step 1: Continue from the step where the drive interrupted	0	×	0A08H
F9.09	PLC status recorded or not at power failure	0: Not save 1: Save	0	×	0A09H
F9.10	Time unit select for each duration	0: Second 1: Minute	0	×	0A0AH

Code	Description	Setting range	Default	Modif y	Modbus Address
	of PLC processing				
F9.11	PLC step1 duration (T1)	0.1~3600	20	o	0A0BH
F9.12	PLC step2 duration (T2)	0.0~3600	20	o	0A0CH
F9.13	PLC step3 duration (T3)	0.0~3600	20	o	0A0DH
F9.14	PLC step4 duration (T4)	0.0~3600	20	o	0A0EH
F9.15	PLC step5 duration (T5)	0.0~3600	20	o	0A0FH
F9.16	PLC step6 duration (T6)	0.0~3600	20	o	0A10H
F9.17	PLC step7 duration (T7)	0.1~3600	20	o	0A11H
F9.18	Step T1 program running setting	1 F/r ~ 4 F/r	1F	o	0A12H
F9.19	Step T2 program running setting	1 F/r ~ 4 F/r	1F	o	0A13H
F9.20	Step T3 program running setting	1 F/r ~ 4 F/r	1F	o	0A14H
F9.21	Step T4 program running setting	1 F/r ~ 4 F/r	1F	o	0A15H
F9.22	Step T5 program running setting	1 F/r ~ 4 F/r	1F	o	0A16H
F9.23	Step T6 program running setting	1 F/r ~ 4 F/r	1F	o	0A17H
F9.24	Step T7 program running setting	1 F/r ~ 4 F/r	1F	o	0A18H
F9.25	②Current step running time	0.0~3600	0	*	0A19H
F9.25	③Current running step	1~7	0	*	0A19H

Code	Description	Setting range	Default	Modify	Modbus Address
F9.26	② Current running step	1~7	0	*	0A1AH
F9.26	③ Current step running time	0.0~3600	0	*	0A1AH
F9.27	Multi-step freq.8	0.00~Max frequency	50.00 Hz	○	0A1BH
F9.28	Multi-step freq.9	0.00~Max frequency	50.00 Hz	○	0A1CH
F9.29	Multi-step freq.10	0.00~Max frequency	50.00 Hz	○	0A1DH
F9.30	Multi-step freq.11	0.00~Max frequency	50.00 Hz	○	0A1EH
F9.31	Multi-step freq.12	0.00~Max frequency	50.00 Hz	○	0A1FH
F9.32	Multi-step freq.13	0.00~Max frequency	50.00 Hz	○	0A20H
F9.33	Multi-step freq.14	0.00~Max frequency	50.00 Hz	○	0A21H
F9.34	Multi-step freq.15	0.00~Max frequency	50.00 Hz	○	0A22H
F9.35	PLC Multi-step Freq.1 selection	0:Multi-step digital setting 1: AI1 2: AI2	0	○	0A23H
F9.36	PLC Multi-step Freq.7 selection	3: keypad potentiometer 4: Pulse input	0	○	0A24H

Group FA: Wobble Frequency

Code	Description	Setting range	Default	Modify	Modbus Address
FA.00	Wobble amplitude	0.0~50.0%	0.0%	○	0B00H
FA.01	Jitter frequency	0.0~50.0%(to FA.00)	0.0%	○	0B01H
FA.02	Jitter Time	5~50ms	5ms	○	0B02H
FA.03	Wobble freq. up time	0.1~999.9s	5.0s	○	0B03H
FA.04	Wobble freq. down time	0.1~999.9s	5.0s	○	0B04H
FA.05	Amplitude mode	0: Relative to the central freq.	0	○	0B05H

Code	Description	Setting range	Default	Modify	Modbus Address
		1: Relative to Max. frequency			

Group Fb: Fixed Length

Code	Description	Setting range	Default	Modify	Modbus Address
Fb.00	Preset length	0~65530	0	○	0C00H
Fb.01	Actual length	0~65530	0	*	0C01H
Fb.02	Pulses number per unit	0.1~6553.0	100	○	0C02H

Group FC: Protection and Fault Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
FC.00	Motor overload protection mode	0: Disabled 1: Common motor (with low speed compensation) 2: Variable frequency motor (without low speed compensation)	1	×	0D00H
FC.01	Electro thermal protection value	20~110% (2) 20~200% (3)	100%	○	0D01H
FC.02	Overload Pre-alarm detection level	30.0~200.0%	160%	○	0D02H
FC.03	Overload Pre-alarm detection time	0.0~80.0s	60.0s	○	0D03H
FC.04	Current amplitude limit	0: Invalid 1: Acc./Dec. valid; Constant speed invalid	2	○	0D04H

Code	Description	Setting range	Default	Modify	Modbus Address
		2: Valid all the time			
FC.05	Current amplitude limit level	Type G: 80.0~200.0% Type P: 60.0~150.0%	G: 160.0% P: 120.0%	○	0D05H
FC.06	Over voltage stall function	0: Invalid (Recommended if braking resistor mounted) 1: Valid for Acc/Dec. 2: Valid all the time	1	×	0D06H
FC.07	Overvoltage point for Acc./Dec. suspend	110.0~150.0% (Bus voltage)	380V: 140% 220V: 120%	×	0D07H
FC.08	Input phase loss detection	1~100% (100% correspond to 800V)	20%	×	0D08H
FC.09	Input phase loss detection delay time	2~255s	10s	×	0D09H
FC.10	Output phase loss detection	0: Invalid 1: Valid	1	○	0D0AH
FC.11	Terminal close fault detection	0: Invalid 1: Valid	1	○	0D0BH
FC.12	Fault auto reset times	0~10, "0" means auto reset is disabled. Only 3 faults have auto reset function	0	×	0D0CH
FC.13	Fault auto reset interval	0.1~20.0s/time	5.0s	×	0D0DH

Code	Description	Setting range	Default	Modify	Modbus Address
FC.14	Under-voltage fault treatment	0: No treatment 1: Auto reset at power recovery 2: Auto run at power recovery (Auto run time interval is F1.16)	0	○	0D0EH
FC.15	Fast current limit	50.0%~100.0% (100% means this function is disabled.)	Depends on model	○	0D0FH
FC.16	Fast current limit time	0.01~1.00s	0.10s② 0.20s③	○	0D10H
FC.17	Ovvoltage suppression freq.	0.00~10.00Hz	0.00Hz	○	0D11H
FC.18	Select suppression overvoltage methods	0: method 1 1: method 2 2: method 3	0	○	0D12H
FC.19	Treatment select while overvoltage forewarning	0: Warning and running still 1: Fault cause stopping	0	○	0D13H
FC.20	Reminding or not while undervoltage	0: Yes 1: No	0	○	0D14H

Group Fd: Communication Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
Fd.00	485 Communication	0: Disabled RS485 1: Enabled RS485	1	○	0E00H
Fd.01	Local address	1~247	1	○	0E01H
Fd.02	Baud rate setup	0: 1200BPS 1: 2400BPS	3②	○	0E02H

Code	Description	Setting range	Default	Modify	Modbus Address
		2: 4800BPS 3: 9600BPS 4: 19200BPS 5: 38400BPS	4(3)		
Fd.03	Parity bit setup	0: Even parity check 1: Odd parity check 2: No parity check	0	○	0E03H
Fd.04	Communication timeout detection duration	Range: 0.0~100.0s 0: No timeout detection Others: Timeout detection duration	0.0s	○	0E04H
Fd.05	Response delay duration	0~500ms	5ms	○	0E05H
Fd.06	Communication Freq. setting coefficient	0.0~200.0%	100.00%	○	0E06H
Fd.07	Communication interrupt detection mode	0: Time interval between 2 packets receiving. 1: Time interval of 0005H Add. data writing	0	○	0E07H
Fd.08	Feedback or not (Y or N) While writing into COMMS setting	0: Y 1: N	0	○	0E08H
Fd.09	Save the COMMS setting or not (Y or N) While power down	0: N 1: Y	0	○	0E09H

Group FE: Operation interface & display

Code	Description	Setting range	Default	Modify	Modbus Address
FE.00	Display	0: Normal 3-levels menu	0	○	0F00H

Code	Description	Setting range	Default	Modify	Modbus Address
	parameter-type setup	display 1: Only display modified parameters			
FE.01	MFK Key function selection	0: MFK inactive 1: JOG running 2: FWD/REV switching 3: UP/DOWN clear 4: Running command switch (terminal or communication) 7: RUN for FWD, MFK for REV, STOP for STOP	0	○	0F01H
FE.02	STOP key function	0: Valid only in keypad control mode 1: Valid in stop state of terminal/ communication control mode 2: Valid in Fault state of terminal/ communication control mode 3: Valid in both stop & fault state of terminal/ communication control mode	2	○	0F02H
FE.03	Running freq.(Hz) (before compensation)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	2	○	0F03H
FE.04	Running freq. (Hz) (After compensation)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F04H
FE.05	Reference frequency (Hz blinking)	0: No display 1: Display at stop 2: Display at running	1	○	0F05H

Code	Description	Setting range	Default	Modify	Modbus Address
		3: Display at stop & running			
FE.06	Output current(A)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	2	○	0F06H
FE.07	Bus voltage (V)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	3	○	0F07H
FE.08	Output voltage (V)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F08H
FE.09	Output torque (%)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F09H
FE.10	Reference torque (% blinking)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F0AH
FE.11	Rotate speed (r/min)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F0BH
FE.12	Reference speed (r/min blinking)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F0CH

Code	Description	Setting range	Default	Modify	Modbus Address
FE.13	Output power (kW)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F0DH
FE.14	AI1 (V)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F0EH
FE.15	AI2 (V)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F0FH
FE.16	Analog PID feedback	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F10H
FE.17	Analog PID setup	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F11H
FE.18	Terminal status (no unit)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F12H
FE.19	Actual length	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F13H
FE.20	Reference length	0: No display 1: Display at stop	0	○	0F14H

Code	Description	Setting range	Default	Modify	Modbus Address
		2: Display at running 3: Display at stop & running			
FE.21	Linear speed (m/min)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F15H
FE.22	External count value (no unit)	0: No display 1: Display at stop 2: Display at running 3: Display at stop & running	0	○	0F16H

Group FF: Running History Record

Code	Description	Setting range	Default	Modify	Modbus Address
FF.00	Type of latest fault	0: NULL 1: Uu1 bus undervoltage 2: OC1 Acc. overcurrent 3: OC2 Dec. overcurrent 4: OC3 Constant speed overcurrent 5: Ou1 Acc. overvoltage 6: Ou2 Dec. overvoltage 7: Ou3 overvoltage in constant speed 8: ② Reserve 8: ③ GF Ground Fault 9: SC Load Short-Circuit 10: OH1 Heatsink overheat 11: OL1 Motor overload 12: OL2 Drive overload 13: EF0 communication	NULL	*	1000H

Code	Description	Setting range	Default	Modify	Modbus Address
		fault 14: EF1 external terminal fault 15: SP1 Input phase failure or input phases unbalance 16: SPO Output phase failure or Unbalance 17: EEP EEPROM Fault 18: CCF Communication between the drive and keypad cannot be established 19: bCE Brake unit fault 20: PCE Parameter copy Error 21: IDE Hall current detection fault 22: ECE PG fault 23: LC fast current limit fault 24: EF2 terminal close fault 25: PIDE: PID feedback offline 26: OLP2 Forewarning of overload fault 27: InPE Initial position fault detected of synchronous moto			
FF.01	Output freq. at latest fault	0~Frequency upper limit	0.00Hz	*	1001H
FF.02	Reference frequency at latest fault	0~Frequency upper limit	0.00Hz	*	1002H

Code	Description	Setting range	Default	Modify	Modbus Address
FF.03	Output current at latest fault	0~2 drive rated current	0.0A	*	1003H
FF.04	Bus voltage frequency at latest fault	0~1000V	0V	*	1004H
FF.05	Running status at latest fault	0: StP Stop 1: Acc acceleration 2: dEc deceleration 3: con constant speed	0	*	1005H
FF.06	Fault history 1 (Last One)	The same as FF.00	NULL	*	1006H
FF.07	Fault history 2	The same as FF.00	NULL	*	1007H
FF.08	Total power on time	0~65530h	0h	*	1008H
FF.09	Total running time	0~65530h	0h	*	1009H
FF.10	Reserved	Reserved	Reserved	-	100AH
FF.11	Software version number of control board	1.00~10.00	1	-	100BH
FF.12	Non-standard version number of software	0~255	0	-	100CH
FF.13	②Heat sink temperature	-30.0~120.0°C	0.0°C	-	100DH
	③IGBT temperature	0.0~140.0°C	0.0°C	-	100DH
FF.14	②Flux current	-200.0~200.0%		*	100EH
FF.15	③Torque current	-200.0~200.0%		*	100FH
FF.17	Accumulated kilowatt-hours (Upper 16)	0~65535kWH	0kWH	-	1011H

Code	Description	Setting range	Default	Modify	Modbus Address
	bits)				
FF.18	Accumulated kilowatt-hours (Low 16 bits)	0~65535kWH	0kWH	-	1012H

Group FP Protection Parameters

Code	Description	Setting range	Default	Modify	Modbus Address
FP.00	User password	0~9999 0: No password Others: password protection	0	○	-
FP.01	Parameter write-in protection	0: All parameters are allowed modifying 1: Only FP.01 and FP.03 can be modified 2: All parameters aren't allowed read	0	○	--
FP.02	Parameter initialization	0: No operation 1: Clear fault history 2: Restore to defaults	0	×	--
FP.03	Parameter copy	0: No action 1: Parameters download 2: Parameters upload(except motor's parameters) 3: Parameters upload (all parameters)	0	×	--
FP.04	Parameter upload protection	0: Protection enabled 1: Protection disabled	0	×	--
FP.05	G/P model selection	0: Type G 1: Type P	0	×	--
FP.07	User	0: Invalid 1: Valid	0	×	--

Code	Description	Setting range	Default	Modify	Modbus Address
	parameters backup				
FP.08	User parameters recovery	0: Invalid 1: Valid	0	x	--

8. Trip information and trouble shooting

Once a trip is detected, NE200&300 would immediately block PWM output and enter the trip protection state; meanwhile TRIP on the keyboard would spark and the LED display the trip code. At this point one must identify the cause of trip and its corresponding solutions according to the method suggested in this section, if it does not work, please contact us immediately. The trip codes and their respective solutions are present in Table 8-1.

Note: A trip code with a sign "③" indicates this trip code is only for NE300

Table 8-1 trip diagnosis and its solutions

Trip code	Trip Type	Possible causes	Solutions
Uu1	Bus Under voltage during running	1.Power grid low voltage	1. Check the input power source.
OC1	Over current in Acceleration	1. Acceleration time too short 2. Power grid low voltage 3. Inverter power rating too small	1. Increase the acceleration time. 2. Check the input power source. 3. Choose inverter with higher capacity.
OC2	Over current in Deceleration	1. Deceleration time too short 2. Large load inertia 3. Inverter power rating too small	1. Increase the deceleration time. 2. Add suitable brake devices. 3. Choose higher capacity drive
OC3	Over current at constant-speed	1 .Abnormal Load mutation 2. Power grid low voltage 3. Inverter power rating too small 4.Encoder sudden offline in	1. Check the load 2. Check the input power source. 3. Choose higher capacity drive 4. Check the encoder and its wiring.

Trip code	Trip Type	Possible causes	Solutions
		closed-loop vector control	
Ou1	Over Voltage in Acceleration	1.Acceleration time too short 2.Power supply abnormal	1. Increase the acceleration time 2. Check the input power source.
Ou2	Over voltage in deceleration	1.Deceleration time too short 2.Large load inertia	1. Increase the deceleration time 2. Add suitable brake devices.
Ou3	Over voltage in constant speed	1. Power supply abnormal 2.Large load inertia	1. Check the input power source. 2. Add suitable braking devices.
GF (3)	Ground Fault	1. One output phase got short circuit problem.	1. Check whether the electric motor insulation is weakening. 2. Check whether the wiring between the frequency converter and the electric motor is damaged.
SC	Load short-circuit	1. Wiring of inverter and motor get phase-to-phase short circuit 2.Damage of the inverting module IGBT	1. Check whether the electric motor coil is short circuit. 2. Ask for the services from manufactures.
OH1	Heat-sink over heat	1. Ambient temperature too high 2. Fan is damaged 3. Fan air duct is blocked	1. Lower the ambient temperature. 2. Change the fan 3. Clear the air duct.
OL1	Motor overload	1. Power supply abnormal 2. Motor rated current set wrongly	1. Check the input power source. 2. Check whether the motor's rated current is correctly set

Trip code	Trip Type	Possible causes	Solutions
		3.The Curve of V/F is not fit 4. Motor always works with heavy load at low speed. 5. Motor blocked to stall or sudden large load change 6.Motor power too low	up. 3. Adjust the V/F curve and torque boosting performance. 4. Use specialized electric motor. 5. Check whether the motor or the load is blocked to stall or not. 6. Use motor and inverter of suitable power ratings
OL2	Inverter overload	1. Low voltage in power grid 2. Load too heavy 3. Acceleration too fast 4.Restart the motor still in turning	1. Check the input power source. 2. Select bigger capacity inverter. 3. Increase the acceleration time 4. Avoid restarting when the motor is in rotation.
EF0	Communication fault	1. Baud rate and parity checksum is set incorrect 2. Communication interrupted for long time	1. Check communication parameters correct or not. 2. Check the interface wiring.
EF1	External terminal fault	1. Faults comes from external control circuit	1. Check the external input
SP1	Input phase loss	1. Input R,S,T have phase loss or imbalance	1. Check input voltage
SPO	Output phase loss	1.There is lack of U,V,W when output 2.There is a serious unbalance in output	1. Check U-V-W motor wiring 2. Check the load
EEP	EEPROM error	1.Function code parameter writing	1. Recover factory defaults

Trip code	Trip Type	Possible causes	Solutions
		error 2. EEPROM damaged	2. Ask for service from supplier
CCF	Keypad & control board communication interrupted	1.Connection cable between keyboard and control panel is broken	1. Check the connection cable between keyboard and control panel
bCE	Brake unit fault	1.The braking line or braking pipe is broken 2.brake resistor is too lower	1. Check the brake unit, change the brake pipe. 2. Choose the suitable braking resistor.
PCE	Parameter copy Error	1. Too long connection cable between keypad and control board leads to interference in parameters transmission. 2. The downloading parameters do not match the existed parameters in the inverter.	1. Shorten the cable between Keyboard and control board to reduce interference. 2. Before downloading, make sure the parameters match the inverter.
IDE	IDE Hall current detection fault	1. The current sensing or hall device get damaged.	1. Ask for service from supplier
ECE ③	Encoder fault	1. Encoder signal wires are connected reversely. 2. Encoder signal wires get damaged. 3. Encoder damaged. 4. Dual-way encoder detected motor direction is not match with	1. Check whether the encoder signal is correctly connected. 2. Check whether the encoder wiring is broke. 3. Change the encoder. 4. Change the encoder direction (F3.16) or alter motor wiring sequence.

Trip code	Trip Type	Possible causes	Solutions
		inverter direction.	
LC	Fast current limit fault	1. Load too large or motor blocked to stall 2. Inverter power rating too small 3. Inverter output circuit loop grounded or SC.	1. Decrease the load and check motor and mechanical part status 2. Choose higher power inverter 3. Remove the external fault
EF2	Terminal close fault	1. The FWD or REV terminals close and get power on. But inverter is set to not allow the restart after power failure recovery.	1. Disconnect the FWD or REV terminal first and then power on the inverter. 2. Close the fault detection function for closed terminal fault (FC.11=0)
PIDE	PID feedback error	1. PID feedback offline	1. Check PID feedback line. 2. Disable PID feedback detection (F8.24=0.0%) 3. Increase PID feedback offline detection time (F8.25)
OLP2	Overload pre-alarm error	1. frequency inverter output current is higher than set pre-alarm threshold	1. Disable pre-alarm function(FC.19=0) 2. Increase pre-alarm threshold value (FC.02) 3. Increase pre-alarm detection time(FC.03)

Hazardous substance limit table for electrical and electronic products

Part Name	Hazardous substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr +6)	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Electronics assembly	X	0	0	0	0	0
Housing assembly	0	0	0	0	0	0
Keypad Battery	0	0	0	0	0	0

This table is in accordance with the provision of SJ/T11364

O: Indicates that said hazardous substance in all of the homogeneous materials for this part is below the limit requirement of GB/T 26572

X: Indicates that said hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement of GB/T 26572.

Inspection Certificate

This document certifies that this product

Inverter

Applied to standards

IEC61800 / EN61800 / GB12668

空白位置宽度为 42mm

was dispatched fully functional tested and inspected in accordance with Control Techniques specifications and drawings.



Operations Director

1st Floor Machinery Building, EVOC Science & Technology Park, No. 11 West Gaoxin Road, Guangming District, Shenzhen, Guangdong
Tel: 0755-86010763

CONTROL 
TECHNIQUES