

# **Modbus-RTU to CC-Link Communication Board Card**

## **User Guide**

Code: 3101A006

Issue: V1.0

Date: 2020.08.10

**Control Techniques China**

**Service Hotline: 400-887-9230**

## Catalogue

Catalogue .....	- 1 -
1. Product Overview .....	- 2 -
1.1 Product function.....	- 2 -
1.2 Main technical parameters .....	- 2 -
1.3 The correspondence example illustration between PLC address and Modbus address.....	- 3 -
1.4 Error Code.....	- 5 -
2. Hardware Description .....	- 7 -
2.1 Product Appearance .....	- 7 -
2.2 LED Indicator Description .....	- 7 -
2.3 Setting CC-Link Slave transmission rate dial - code switch ...	- 9 -
2.4 Setting CC-Link Slave Address Dial - code Switch .....	- 9 -
2.5 CC-Link Interface .....	- 10 -
2.6 VFD interface pin definition.....	- 10 -
2.7 Installation Dimension.....	- 11 -
3. Product Application Topology .....	- 11 -
4. Test with Mitsubishi QJ61BT11N.....	13

# 1. Product Overview

## 1.1 Product function

This communication board could realize the conversion between MODBUS-RTU and CC-Link of field bus, and it could be applied with VFD NE-300/600. The RS485 interface of the board works as the Modbus master while the CC-Link interface works as the slave.

## 1.2 Main technical parameters


1. Supports CC-Link Ver.2
2. CC-Link communication rate :( 10M/5M/ 2.5M /625K/156Kbps)
3. Number of memory stations occupied by CC-Link communication: 3 stations (not modifiable)
4. CC-link communication extended loop station setting: 8 times (not modifiable)
5. Modbus function code supported by ModbusRTU communication board: 03/06
6. Modbus slave address read by ModbusRTU communication board: 1 (not modifiable)
7. Baud rate of ModbusRTU communication board: 19200bps (not modifiable)
8. ModbusRTU communication setting on the communication board: data bit is 8, even check, 1 stop bit (not modifiable)
9. Working voltage: 24VDC, 5VDC
10. Working environment temperature: -40 ~ 85°C, relative humidity: 5 ~ 95% (no condensation)
11. Storage temperature: -55 ~ 125°C
12. Installation: Fix it in the VFD with 3 pc of screws
13. Dimensions: 90.37\*22\*182(L \* W \* H, unit: mm)
14. Protection level: IP20

**Note: Before using the board card, the VFD parameters should be set as follows:**

Function code	Name	Set Value
F0.02	Run command control mode settings	2
F0.03	Frequency setting 1	4
F0.04	Frequency setting 1	4
Fd.00	485 communication function	1
Fd.01	IP Address	1
Fd.02	Baud rate selection	4

Fd.03	Parity check selection	0
-------	------------------------	---

### 1.3 The correspondence example illustration between PLC address and Modbus address



1. For example, D1000-D1029 read the data address of NE300/600 for PLC, and D2000-D2003 wrote the data address of NE300/600 for PLC. See the table below:

D1000-D1029 IW Input address, D2000-D2006 QW Output address Description				
	PLC data address	Data type	Modbus RTU address	Description
<b>P</b> <b>r</b> <b>o</b> <b>c</b> <b>e</b> <b>s</b> <b>s</b>	D2000	WORD	Write area 4 address 40001	write communication commands
	D2001	WORD	Write area 4 address 40002	Write communication set value address
	D2002	WORD	Write area 4 address 40003	Write output terminal definition
	D2003	WORD	Write area 4 address 40004	Write Analog Output Setting
<b>D</b> <b>a</b> <b>t</b> <b>a</b>	D1000	WORD	Read area 4 address 40001	Read communication control commands
	D1001	WORD	Read area 4 address 40002	Read communication set value address
	D1002	WORD	Read area 4 address 40003	Read output terminal definition
	D1003	WORD	Read area 4 address 40004	read analog output setting
	D1004	WORD	Read area 4 address 40020	Read VFD state
	D1005	WORD	Read area 4 address 40021	read failure content
	D1006	WORD	Read area 4 address 40022	read alarm content

## Modbus-RTU to CC-Link Communication Board Card User Guide

D1007	WORD	Read area 4 address 40023	Read running frequency
D1008	WORD	Read area 4 address 40024	Read set frequency
D1009	WORD	Read area 4 address 40025	Read bus bar voltage
D1010	WORD	Read area 4 address 40026	Read output voltage
D1011	WORD	Read area 4 address 40027	Read output current
D1012	WORD	Read area 4 address 40028	Read operating rotate speed
D1013	WORD	Read area 4 address 40029	read output frequency
D1014	WORD	Read area 4 address 4002A	read output torque
D1015	WORD	Read area 4 address 4002B	Read PID set value
D1016	WORD	Read area 4 address 4002C	Read PID feedback value
D1017	WORD	Read area 4 address 4002D	Read analog AI1
D1018	WORD	Read area 4 address 4002E	Read analog AI2
D1019	WORD	Read area 4 address 4002F	Reserved
D1020	WORD	Read area 4 address 40030	Read terminal state
D1021	WORD	Read area 4 address 40031	Reserved
D1022	WORD	Read area 4 address 40032	Reserved
D1023	WORD	Read area 4 address 40033	Reserved
D1024	WORD	Read area 4 address 40034	Read external counting
D1025	WORD	Read area 4 address 40035	Read X1 state
D1026	WORD	Read area 4 address 40036	Read X2 state
D1027	WORD	Read area 4 address 40037	Read X3 state
D1028	WORD	Read area 4 address 40038	Read X4 state
D1029	WORD	Read area 4 address 40039	Read X5 state

### 2. Address read of D1030-D1033

D1030 Input Data							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	1 means IB9 write error	1 means IB8write error	1means IB7write error	1 means IB9 write error	1 means IB5 read error	1 means IB4 read error	1 means IB3 read error
Data address	Data bit	Data type	Description				Error
D1030	8-F	Byte	Command 1 error code(read area 4 1-4)				

## Modbus-RTU to CC-Link Communication Board Card User Guide

D1031	0-7	Byte	Command 2 error code(read area 4 20-2F)	code see 1.4
D1031	8-F	Byte	Command 3 error code(read area 4 30-39)	
D1032	0-7	Byte	Command 4 error code(write 40001)	
D1032	8-F	Byte	Command 5 error code(write 40002)	
D1033	0-7	Byte	Command 6 error code(write 40003)	
D1033	8-F	Byte	Command 7 error code(write 40004)	

3. Read address D1034-D1037 of NE300/600, and wrote to address D2004-D2006 of NE300/600.

Slot 3 IW Input Address, QW output address description			
	Data Address	Data Type	Description
EEPROM Control	D2004	WORD	Wrote to EEPROM parameter address
	D2005	WORD	Wrote to EEPROM parameter data
	D2006	WORD	Wrote to EEPROM enable(1 valid)
	D1034	WORD	Read address which was written to EEPROM
	D1035	WORD	Read data which was written to EEPROM
	D1036	WORD	Read enable state(1 is normal)
	D1037	WORD	Read and wrote state(0 is normal)

### 1.4 Error Code

Error Code	Failure Description	Troubleshooting
0x00	Slave works normally	N/A
0x01	Illegal function code	Slave does not support the current function code, please refer the slave user manual and choose relevant function code.
0x02	Illegal data address	Slave address exceeds its address range
0x03	Illegal data value	Data length error
0x04	Slave device failure	Checking slave device state
0x06	Slave device busy	Checking slave device state
0x07 0x02	Parity checking error	Checking parity checking, baud rate and stop bit
0x08	Reserved	Reserved
0x09	CRC checking error	Slave response message CRC calculation error, checking slave state.
0x0B	Slave device responding timeout	Increasing timeout time, check hardware connection state, check baud rate and other communication parameter Settings.


## Modbus-RTU to CC-Link Communication Board Card User Guide

---

0x0E	Error in response message length	Increasing the receiving character spacing
0x0F	Writing slave device response error	Checking hardware connection state

## 2. Hardware Description

### 2.1 Product Appearance



### 2.2 LED Indicator Description

The equipment has five LED state indicators, whose symbol definition and state description are shown in "Table 2.2".

Table2.2 LED Indicator Description

Symbol	Definition	State	Description
D2	CC Link is normal	Green LED on	CC Link Bus communication is normal
D1	CC Link is in error	Red LED on	CC Link Bus communication is in error
D9	Serial port sending data	Green LED flashing	Serial port is sending data
		Green LED not flashing	Serial port is not sending data
D8	Serial port receiving data	Green LED flashing	Serial port is receiving data
		Green LED not flashing	Serial port is not receiving data



## Modbus-RTU to CC-Link Communication Board Card User Guide

---

D10	Power Indicator	Red LED on	Power connected
		Red LED off	Power not connected

## 2.3 Setting CC-Link Slave transmission rate dial - code switch



Transmission rate dial - code switch

CC-Link supports transmission rate as: 156kbps, 625kbps, 2.5Mbps, 5Mbps, 10Mbps

When the dial code switch is dialed to 0, the transmission rate is: 156kbps

When the dial code switch is dialed to 1, the transmission rate is: 625kbps

When the dial code switch is dialed to 2, the transmission rate is: 2.5Mbps

When the dial code switch is dialed to 3, the transmission rate is: 5Mbps

When the dial code switch is dialed to 4, the transmission rate is: 10Mbps

When the dial code switch is dialed to 5, 6, 7, 8, 9 and the transmission rate is: 156kbps

## 2.4 Setting CC-Link Slave Address Dial - code Switch



Slave ones dialing


Slave tens dialing

As shown in the above PIC, the high-order dial-code switch (X10) set by CC-Link slave address is dialed to 0, and the low-order dial-code switch (X1) is dialed to 2, so this is indicating that the slave address of this module in CC-Link network is set as:

0\*10+2=2.

Cc-link slave valid address range is 1-64, after the dial code exceeds the range, the default setting of the board card is: 1.

## 2.5 CC-Link Interface




CC-Link communication interface pin definition is as below:


DA	Signal DA
DB	Signal DB
DG	Signal Ground
SLD	Shielding Ground
FG	Grounding

## 2.6 VFD interface pin definition


Pin No.	Signal Name	Definition
1	COM	GND of 24V
2	VCC	+5V output voltage
3	P24	+24V output voltage
4	GND	GND of 5V
12	GND	GND of 5V
15	485+	Receiving and sending data –P (Modbus-RTU interface)
16	485-	Receiving and sending data –N (Modbus-RTU interface)



### 2.7 Installation Dimension





### 3. Product Application Topology



## 4. Test with Mitsubishi QJ61BT11N

4.1. Opening the GX Works2 software, and create a new project, then select the CPU series and model.



4.2. Clicking "Parameters" under the left project tree → "Network Parameters" → double-clicking "CC Link" to configure CC Link communication parameters.

# Modbus-RTU to CC-Link Communication Board Card User Guide

Number of modules: 1

Type: Master

Mode Setting: Remote Network (Ver 2 mode)

Total number of connections: 1

Remote register (RW<sub>r</sub>): set to D1000 (programmatically defined)

Remote register (RW<sub>w</sub>): Set to D2000 (programmatically defined)

Station information: Ver.2 Remote equipment station (fixed 8 times setting, occupying 3 stations)

Module numbers

模块块数	1	2	3	4
起始/IO号	Master			
运行设置	运行设置			
类型	主站			
数据链接类型	主站CPU参数自动启动			
模式设置	远程网络(Ver.2模式)			
总连接台数	1			
远程寄存器(RW <sub>r</sub> )	D1000			
远程寄存器(RW <sub>w</sub> )	D2000			
站信息设置	站信息			
远程设备站初始设置	初始设置			
中断设置	中断设置			

Network Parameters

remote network


Numbers of the slave devices connected


表示连接从站设备的台数


PLC读写从站数据的寄存地址

Register address of the slave data read and written by the PLC

## Modbus-RTU to CC-Link Communication Board Card User Guide



4.3. After the configuration is finished → clicking  in the menu bar to download to the PLC.



4.4. Clicking the "Online" in the toolbar → the "Monitor" in the drop - down menu → Soft Component/Buffer Bulk Monitoring in the drop - down menu.



# Modbus-RTU to CC-Link Communication Board Card User Guide

